

EMERGENCY KEY OVERRIDE & CODE FINDER FUNCTION

INSERT MASTER KEY OVERRIDE & TURN
KEY 75° CLOCKWISE (SEE PICTURE 3)



TURN HANDLE TO OPEN POSITION

LIGHTLY ROTATE INDIVIDUAL WHEELS UPWARDS
UNTIL EACH ONE LOCKS INTO POSITION
(USER CODE IDENTIFIED)

TURN KEY 75° ANTI-CLOCKWISE
& REMOVE FROM LOCK

REFER TO USER INSTRUCTIONS FOR
PROCEDURE TO SET NEW USER CODE

PICTURE 3



INSTALLATION AND USER INSTRUCTIONS

Gemini Mechanical 2700

Special Notes

Before installing the Gemini Mechanical Lock, familiarise yourself with the operation and functions.

Unless manufactured to special order:-

The default User Code is 2244.

This code is common to all standard locks and it is very important that you set your own personal User Code. Your lock is not secure until you have changed the default User Code.

Keep a safe record of your User Code.

L&F A Lowe & Fletcher Group Company

Lowe & Fletcher Ltd (UK)

T: + 44 (0) 121 505 0400
E: sales@lowe-and-fletcher.co.uk
W: www.lowe-and-fletcher.co.uk

Lowe & Fletcher Inc (USA)

T: +1 (0) 616 994 0490
E: sales@loweandfletcherinc.com
W: www.loweandfletcherinc.com

Euro-Locks SA NV (Belgium)

T: +32 (0)61 212 261
E: sales@euro-locks.be
W: www.euro-locks.be

Euro-Locks SA (France)

T: +33 (0)3 87 92 61 11
E: euro-locks@euro-locks.fr
W: www.euro-locks.fr

Euro-Locks GmbH (Germany)

T: +49 (0)6897 9072 0
E: vertrieb@euro-locks.de
W: www.euro-locks.de

Euro-Locks Sp. z o (Poland)

T: +48 (32) 344-78-70, -82, -84
E: sekretariat@euro-locks.pl
W: www.euro-locks.pl

Gemini)C
digital and mechanical locks

INSTALLATION AND USER INSTRUCTIONS

Gemini Mechanical 2700

The 2700 lock can be installed in two ways:

Surface Mount (accessory kit 951700_)

Flush Mount (accessory kit 951600_)

Surface Mount

Step 1 Remove all packaging.

Step 2 Fit the surface mount sleeve to lock as shown in Picture 1.

Step 3 Position the lock on the outside of the door as shown in Picture 2.

Step 4 Holding the lock in position, fit the 2 x M4 pan head screws (supplied with the surface mount sleeve) as shown in Picture 3.

Step 5 Tighten the 2 x M4 screws using a No.2 Posidriv® to 1Nm.

Step 6 Position the cam onto the rear of the lock as required, fit the cam washer and fixing screw as shown in Picture 6.

Step 7 Tighten the cam fixing screw using a No.2 Posidriv® to 1.5Nm. Take care not to damage the screw thread when fitting the screw.

Step 8 Before closing the door, test the lock by selecting the correct User Code and rotating 90°.

Step 9 Your lock should now be ready to use.

Flush Mount

Step 1 Remove all packaging.

Step 2 Position the lock on the outside of the door as shown in Picture 4.

Step 3 Holding the lock in position, fit the clamp box and 2 x M4 pan head screws (supplied with the clamp box) as shown in Picture 5.

Step 4 Tighten the 2 x M4 screws using a No.2 Posidriv® to 1Nm.

Step 5 Position the cam onto the rear of the lock as required, fit the cam washer and fixing screw as shown in Picture 6.



Step 6 Tighten the cam fixing screw using a No.2 Posidriv® to 1.5Nm. Take care not to damage the screw thread when fitting the screw.

Step 7 Before closing the door, test the lock by selecting the correct User Code and rotating 90°.

Step 8 Your lock should now be ready to use.

Picture 1.

Fit surface mount sleeve to lock as shown.




Picture 2.

Position lock on door panel as shown.

Picture 3.

Fit 2 x M4 pan head screws as shown.





Picture 4.

Position lock through door panel as shown.

Picture 5.

Fit clamp box and 2 x M4 pan head screws as shown.



Picture 6.

Fit cam, washer & screw. Tighten with No.2 Posidriv®.

NOTE: User mode MUST be specified on order.
Lock cannot be changed between Public and Private Mode.


USER INSTRUCTIONS (PUBLIC MODE)

WITH THE LOCK IN THE "OPEN" POSITION,
(SEE PICTURE 1a)
ROTATE WHEELS TO SELECT A NEW USER CODE


TURN THE HANDLE TO THE "CLOSED" POSITION
(SEE PICTURE 1b)

SCRAMBLE CODE TO SECURE &
CHECK TO ENSURE LOCKED

PICTURE 1a
("UNLOCKED" POSITION)



PICTURE 1b
("LOCKED" POSITION)



USER INSTRUCTIONS (PRIVATE MODE)

SET A NEW USER CODE


OPEN LOCK USING CURRENT USER CODE
(DEFAULT 2 2 4 4)

TURN HANDLE 135° TO CODE CHANGE POSITION
(OPEN POSITION 90° + FURTHER 45°)
SEE PICTURE 2a FOR LEFT-HAND VERSION = CCW
& 2b FOR RIGHT-HAND VERSION = CW


ROTATE INDIVIDUAL WHEELS TO SELECT
NEW USER CODE

TURN HANDLE 45° TO OPEN POSITION TO
SET USER CODE

CLOSE DOOR, ROTATE HANDLE FULLY TO CLOSED
POSITION & SCRAMBLE CODE



PICTURE 2a
(LEFT-HAND)



PICTURE 2b
(RIGHT-HAND)

OPEN SELECT USER CODE & TURN HANDLE (RH = CW, LH = CCW)
CLOSE TURN HANDLE & SCRAMBLE CODE (RH = CCW, LH = CW)